



SNYPER-LTE Graphyte Case Contents

- 1 SNYPER-LTE Graphyte with support cradle underneath
- 2 PSU with 4 adapter heads (Not included with the SNYPER-LTE Graphyte AP Variant)
- 3 2x USB cables - 0.5m and 1.8m
- 4 Omni-directional Antennas - General Purpose (Black) and 2600MHz (Silver/Grey)*
- 5 LiveSCAN Directional Antenna
- 6 Extension Cable for Directional Antenna
- 7 Tripod








*2600MHZ (Silver/Grey) antenna supplied for EU model only

· FIRST STEP BEFORE USE


- ↳ **BATTERY CHARGE**
Charge the unit for 4-6 hours or until the red charge light is extinguished.
- ↳ **SET TIME**
 - 1) Power up the SNYPER 
 - 2) Select 'Setup' from the 'Main Menu'
 - 3) Select 'Set Time'
 - 4) Use the keypad arrows to set date/timeUse  **BACK** key to exit
- ↳ **ANTENNA SELECTION**
Screw in appropriate supplied antenna* (dependant on survey type - Please refer to user manual).
- ↳ **SOFTWARE UPDATE**
Go to <https://www.siretta.com/snyper-plus> to check for latest software.
- ↳ Your SNYPER is now ready to use




· SURVEY

- ↳ **NEW SURVEY OPTIONS**
 - 1) Select Full, LTE, UMTS or GSM**
 - 2) Select number of cycles and time interval
 - 3) Connect charger to extend surveys
 - 4) Press  to start survey
 - 5) Leave device to complete surveys
- ↳ **POST SURVEY OPTION 1**
 - 1) Select 'Show Results'
 - 2) Press  to start LiveSCANUse  **BACK** key to exit
- ↳ **POST SURVEY OPTION 2**
 - 1) Select 'Show Summary'Use  **BACK** key to exit
- ↳ **POST SURVEY OPTION 3**
 - 1) Select 'Save Results'This is only necessary if Auto Save is off
Use  **BACK** key to exit


· SAVED RESULTS

- ↳ **STORED SURVEY**
 - 1) Select results file you wish to view
 - 2) Select 'Show Results', 'Show Summary' or 'Export Results'Use  **BACK** key to exit


· SETUP

- ↳ Language: EN/DE/FR/IT/ES
Display: Screen brightness, text colours and disk monitor
Auto off: Auto switch off and dimming
Documents: File types and Auto Save
Sound: On/Off
System: Mode and region of operation
Set Time: Set date and time
Reset Menu: Return to default settings
Use  **BACK** key to exit

· ABOUT

- ↳ Key reference parameters about the device
Use  **BACK** key to exit

· PC CONNECT

- ↳ **PC CONNECT**
 - 1) Connect USB cable between device and PC
 - 2) Select ON to enable USB connection, begin results download
 - 3) Copy files required to PC
 - 4) Select OFF to disable connectionUse  **BACK** key to exit
You can then view results files on your PC

For safety documents, please visit:
<https://www.siretta.com/safety/>

*The General Purpose (Black) antenna covers most frequencies and is commonly used.

**The (USA) and (AP) models do not survey the GSM band.